

การตั้งค่า TL-MR6500v สำหรับ NT wireless net

Advanced

- ❖ Network
 - Internet
 - Network Mode -> 4G Preferred
 - Profile Name -> pocket
 - APN Type -> Static
 - APN -> pocket
- ❖ Wireless
 - Wireless Settings
 - Enable Wireless Radio -> Enable
 - Network Name (SSID) -> NT2300
 - Password -> net2300LTE
- ❖ System Tools
 - CWMP Settings
 - CWMP -> Enable
 - Inform -> Enable
 - Inform Interval -> 300
 - ACS URL -> <http://monitor.totwirelessnet>
 - ACS Username -> monit
 - ACS Password -> 9@ng!4Ak\$9
 - Interface used by TR-069 client -> Any WAN
 - Connection Request Authentication -> Enable
 - Username ->
 - Password ->
 - Path -> /tr069
 - Port -> 2300